Vertrel™ XP

Specialty Fluid

Removes Particulate and Ionic Soils

Technical Information

Introduction

Vertrel™ XP is a proprietary azeotrope of Vertrel™ XF hydrofluorocarbon (2,3-dihydrodecafluoropentane) and isopropanol. It is ideally suited for use in vapor degreasing equipment. It offers improved solvency for polar soils, compared to Vertrel™ XF, while maintaining excellent compatibility with most plastic, ceramic, and metal components. Typical applications include precision and specialty cleaning and rinsing for removal of particulate, light soils, and fingerprints from plastic, glass, and metal parts.

Vertrel™ XP has zero ozone depletion potential (ODP) and low global warming potential (GWP). It can replace CFC-113, 1,1,1-trichloroethane (1,1,1-TCA), hydrochlorofluorocarbons (HCFCs), and perfluorocarbons (PFCs) in many applications. Vertrel™ XP is accepted by the U.S. Environmental Protection Agency (EPA) under the Significant New Alternatives Policy (SNAP) program as a substitute for ozone-depleting substances.

The unique properties of Vertrel[™] XP (**Tables 1** and **2**) include a high density, low viscosity, and low surface tension for effective particle and soil removal.

Cleaning Process

Vapor degreasing should be used for optimum cleaning effectiveness and economy. Modern vapor containment technology is recommended for both batch and in-line equipment. These systems have higher freeboard and a secondary set of low temperature (-29 °C [-20 °F]) condenser coils to greatly reduce vapor losses.

Cleaning Applications

Vertrel™ XP is ideally suited for cleaning fine particulate matter (submicron range) from metal and nonmetal parts. Contaminants, such as dust particles, skin flakes, fibers, and other process contaminants, tend to bond with the surface of the part by some physical force, such as electrostatic forces or a mechanical entrapment due to the surface geometry. Removal of these contaminants requires a solvent that can reduce the laminar boundary layer thickness to allow particles to be washed away by the liquid solvent flow-through.

A thin boundary layer and higher liquid flow-through momentum can be accomplished with a solvent, such as Vertrel™ XP, which has a high density, low viscosity, and low surface tension, so that fine particles can be debonded efficiently. Typical applications include pre-sputter cleaning of disk media, head stack assemblies, and lenses for optical devices. The versatility of Vertrel™ XP allows it to be used in other industries with other precision cleaning applications.



Vertrel[™] XP Specialty Fluid

Table 1. Physical Properties

Table 1.1 Hysicari Toperties	
Property ^a	Vertrel [™] XP
Molecular Weight	228
Boiling Point, °C (°F)	52 (126)
Liquid Density, kg/L	1.53
Vapor Pressure, atm	0.334
Surface Tension, N/m	0.0151
Freezing Point, °C (°F)	<-80 (<-112)
Heat of Vaporization at Boiling Point, kJ/kg	TBD
Heat Capacity, kJ/kg·°C	TBD
Viscosity, cP	0.68
Flash Point Closed Cup, °C Open Cup, °C	None ^b None ^c
Vapor Flammability in Air, vol% Lower Limit Upper Limit	None None

^aAt 25 °C (77 °F), except where indicated.

Table 2. Density and Vapor Pressure Change with Temperature

Temperature, °C (F)	Density, kg/L	Vapor Pressure, atm
0 (32)	1.591	0.094
10 (50)	1.564	0.161
20 (68)	1.537	0.267
25 (77)	1.530	0.334
30 (86)	1.510	0.421
40 (104)	1.483	0.638
50 (122)	1.456	0.933
60 (140)	1.429	1.324

Plastic and Elastomer Compatibility

Most plastics and elastomers can be safely cleaned in Vertrel™ XP. **Tables 3** and **4** summarize test results on short-term exposures of unstressed plastics and elastomers, simulating a typical cleaning cycle.

Long-term compatibility data simulating exposure of vapor degreaser construction materials is available from Chemours upon request.

Table 3. Plastic Compatibility Immersion: 15 Minutes at Room Temperature

Compatible		
Polyethylene	ABS	
Polypropylene	Acetal	
Polystyrene	Acrylic	
Polyester, PET, PBT	Ероху	
Polyphenylene Oxide, PPO	lonomer	
Polyimide, PI, PEI, PAI	Liquid Crystal Polymer	
Polyetherketone, PEK	Phenolic	
Polyaryletherketone, PEEK	PVC, CPVC	
Polysulfone	PTFE, ETFE	
Polyarylsulfone	Cellulosic	
Polyphenylene Sulfide, PPS		
Incompatible*		
None Tested		

^{*}Material composition varies, depending upon compounding agents, plasticizers, processing, etc. Specific materials should be tested for compatibility with solvent.

Table 4. Elastomer Compatibility Immersion: 15 Minutes at Room Temperature

Compatible		
Buna N, NBR, Nitrile	Buna S, SBR, GRS	
Butyl Rubber, IIR	Chlorosulfonated PE	
EPM, EPDM, Nordel®	Polysulfide	
Natural Rubber, Isoprene	Neoprene	
Viton™ B	Urethane	
Silicone		
Incompatible*		
None Tested		

^{*}Material composition varies, depending upon compounding agents, plasticizers, processing, etc. Specific materials should be tested for compatibility with solvent

Elastomer swelling and shrinking will, in most cases, revert to within a few percent of original size after air drying. Swell, shrinkage, and extractables are strongly affected by the compounding agents, plasticizers, and curing used in the manufacture of plastics and elastomers. Therefore, prior in-use testing is particularly important.

Metals and Other Compatibility

Vertrel[™] XP was found compatible with stainless steel, aluminum, copper, and brass after exposure for two weeks at 100 °C (212 °F) in sealed tubes.

^bTag Closed Cup Tester (ASTM D56-93)

^cTag Open Cup Tester (ASTM D1310-86)

Vertrel[™]XP Specialty Fluid

Large amounts of water may extract alcohol and affect cleaning performance. Therefore, to reduce alcohol loss, use desiccant dryers, rather than water separators, in the condensate return line.

Contact with highly basic process materials, pH 10 or above, is not recommended.

Exposure Limits

Data from toxicity studies has demonstrated that Vertrel™ XP has low toxicity. It is a slight skin and eye irritant and has low inhalation toxicity. **Table 5** shows the applicable exposure limits for the component materials of Vertrel™ XP.

Table 5. Exposure Limits

Component	Lir	nit, ppm	Туре
Vertrel™ XF	AELa	200 400	8- and 12-hr TWA Ceiling ^b
Isopropanol	AEL TLV ^c STEL ^d	200 200 400	8- and 12-hr TWA 8-hr TWA
Vertrel™ XP	AEL ^{a, b}	200	Calculated ^e

^aAcceptable Exposure Limit (AEL) is an airborne inhalation exposure limit established by Chemours that specifies time-weighted average (TWA) concentrations to which nearly all workers may be repeatedly exposed without adverse effects.

^bA ceiling limit is the concentration that should not be exceeded during any part of the working day. The ceiling limit for individual components applies to the blend product as well.

^cThreshold Limit Value (TLV) is an air-borne inhalation exposure limit established by the American Conference of Government and Industrial Hygienists (ACGIH) that specifies time-weighted average concentrations to which nearly all workers may be repeatedly exposed without adverse effects.

dSTEL is the short-term exposure limit established by ACGIH.

^eCalculated in accordance with ACGIH formula for TLVs for mixtures

Safety/Flammability

Vertrel™ XP exhibits no closed cup or open cup flash point and is not classified as a flammable liquid by NFPA or DOT. In addition, the product has no vapor flammability limits in air.

Flash point data and limits of flammability in air provide the user with additional information that should be used as elements of a fire risk assessment and to determine guidelines for the safe handling of volatile chemicals. Users should ensure compliance with NFPA standards and local fire codes.

Recovery

Due to the azeotropic nature of Vertrel™ XP, the product is easily recoverable by off-line or in-line distillation equipment, such as a vapor degreaser or still. The presence of soil, however, may alter the characteristics of the material during the recovery operation. Recovery should be closely monitored to ensure operating levels are maintained. Users should test the spent Vertrel™ XP to ensure proper classification for waste disposal.

Storage/Handling

Vertrel™ XP is thermally stable and does not oxidize or degrade during storage. Store in a clean, dry area. Protect from freezing temperatures. If solvent is stored below -10 °C (14 °F), mix prior to use. Do not allow stored product to exceed 52 °C (125 °F) to prevent leakage or potential rupture of container from pressure and expansion.

Consideration should be given to retrofit of existing, or purchase of new, vapor degreasing equipment to provide vapor containment technology that enables safe and economical use of Vertrel^M XP.

Drum pumps are recommended to dispense Vertrel™ XP from its container. Refer to the Safety Data Sheet (SDS) for specific handling precautions and instructions.

Environmental Properties

Vertrel[™] specialty fluids have zero ozone depletion potential and low global warming potential (**Table 6**). They are used as alternatives to CFC-113, methylchloroform, hydrochlorofluorocarbons (HCFCs), and perfluorocarbons (PFCs) in many critical cleaning, drying, carrier fluid, and other high-value specialty uses where reliability is paramount.

Vertrel™ XP is accepted by the U.S. Environmental Protection Agency (EPA) under the Significant New Alternatives Policy (SNAP) program as a substitute for ozone-depleting substances.

Table 6. Environmental Properties

Property	Vertrel™ X-P10
Ozone Depletion Potential (ODP)	0
Global Warming Potential (GWP/100 yr ITH)*	1,258
Volatile Organic Compounds (VOC, g/L)	49.7

^{*}IPCC Second Assessment Report (1995)

Vertrel[™] XP Specialty Fluid

Packaging and Availability

Vertrel™ XP is commercially available in 55-gal (208-L) drums with a net weight of 600 lb (272 kg) and in 5-gal (19-L) pails with a net weight of 55 lb (25 kg). One-gallon and smaller samples in glass containers are available on request. Customers are encouraged to secure samples now for compatibility and performance testing.

Specifications

Composition and specifications are shown in **Table 7**. All components are listed in the TSCA Inventory.

Table 6. Vertrel[™] XP Specifications

Property	Vertrel™ XP
Vertrel™ XF, wt%	96.75% ± 0.2
Isopropanol, wt%	3.25% ± 0.2
Nonvolatile Residue, ppm wt	2.0 max
Moisture, ppm wt	200 max.
Appearance	Clear, colorless

For more information on Vertrel $^{\text{\tiny TM}}$, please visit vertrel.com or call (800) 235-7882.

The information set forth herein is furnished free of charge and based on technical data that Chemours believes to be reliable. It is intended for use by persons having technical skill, at their own risk. Because conditions of use are outside our control, Chemours makes no warranties, expressed or implied, and assumes no liability in connection with any use of this information. Nothing herein is to be taken as a license to operate under, or a recommendation to infringe, any patents or patent applications.

© 2016 The Chemours Company FC, LLC. Vertrel[™] and any associated logos are trademarks or copyrights of The Chemours Company FC, LLC. Chemours [™] and the Chemours Logo are trademarks of The Chemours Company.

Replaces: K-04165-2 C-11056 (11/16)